






SCHEDA TECNICA COMPONENTI









ATTENZIONE: INTERVENTI DA ESEGUIRE ESCLUSIVAMENTE DA PERSONALE TECNICO QUALIFICATO IN ASSENZA DI ALIMENTAZIONE ELETTRICA.

- 1 - SCHEDA ALIMENTAZIONE
- 2 - SCHEDA CPU
- 3 - TASTIERA
- 4 - MODULO 2 CANALI ESTRAIBILE
- 5 - CONNETTORE RESISTENZE 230 VOLT (ZONE DA 9 A 16)
- 6 - CONNETTORE RESISTENZE 230 VOLT (ZONE DA 1 A 8)
- 7 - CONNETTORE TERMOCOPPIE (ZONE DA 9 A 16)
- 8 - CONNETTORE TERMOCOPPIE (ZONE DA 1 A 8)
- 9 - PRESA ALLARMI 230 VOLT MAX 10 WATT
- 10 - FUSIBILE VENTILAZIONE 5X20 - 6X30 DA 5 AMP. (SE VENTILATA)
- 11 - FUSIBILE BOBINA DI MINIMA TENSIONE 5X20 - 6X30 DA 3 AMP. (SE PREDISPOSTA)
- 12 - INTERRUOTORE GENERALE
- 13 - BOBINA DI MINIMA TENSIONE 230 V

- 14 - SPIE CONTROLLO FASI (L1 - L2 - L3)
- 15 - FUSIBILE PROTEZIONE (ZONA A) MAX 16 AMPERE FF
- 16 - FUSIBILE PROTEZIONE (ZONA B) MAX 16 AMPERE FF
- 17 - FUSIBILE PROTEZIONE SPIE CONTROLLO FASI (ALL'INTERNO)
- 18 - SCHEDA BUS A
- 19 - SCHEDA BUS B
- 20 - SPIE CONTROLLO ZONE
- 21 - FUSIBILE PROTEZIONE SPIE CONTROLLO ZONE (ALL'INTERNO)
- 22 - SCHEDA ALIMENTAZIONE
- 23 - SCHEDA CPU
- 24 - CASSETTO DI VENTILAZIONE 230 V 45 W
- 25 - FUSIBILE SCHEDA ALIMENTAZIONE 1A
- 26 - PRESA CONSENSO DALLA PRESSA

COMPONENT'S TECHNICAL CARD



ATTENTION: ONLY AUTHORIZED PEOPLE CAN HANDLE WITHOUT ELECTRICAL FEEDING

- 1 - FEEDING CARD
- 2 - CPU CARD
- 3 - KEYBOARD
- 4 - 2 CHANNELS EXTRACTABLE MODULE
- 5 - RESISTANCES CONNECTORS 230 VOLT (ZONES FROM 9 TO 16)
- 6 - RESISTANCES CONNECTORS 230 VOLT (ZONES FROM 1 TO 8)
- 7 - THERMOCOUPLES CONNECTORS (ZONES FROM 9 TO 16)
- 8 - THERMOCOUPLES CONNECTORS (ZONES FROM 1 TO 8)
- 9 - ALARMS PLUG 230 VOLT MAX 10 WATT
- 10 - VENTILATION FUSE 5X20 - 6X30 OF 3 AMP. (IF DISPOSED)
- 11 - COIL FUSE OF MINIMAL TENSION 5X20 - 6X30 DA 3 AMP. (IF PREDISPOSED)
- 12 - GENERAL SWITCH
- 13 - MINIMUM TENSIONE COIL 230 V

- 14 - LIGHTS OF FASES CONTROL (L1-L2-L3)
- 15 - PROTECTION FUSE (ZONE A) MAX 16 AMPERE FF
- 16 - PROTECTION FUSE (ZONE B) MAX 16 AMPERE FF
- 17 - PROTECTION FUSE FOR FASES CONTROL LIGHTS (INSIDE)
- 18 - BUS CARD A
- 19 - BUS CARD B
- 20 - LIGHTS OF ZONES CONTROL
- 21 - PROTECTION FUSE FOR ZONE CONTROL LIGHTS (INSIDE)
- 22 - FEEDING CARD
- 23 - CPU CARD
- 24 - VENTILATION DRAWER 230 V 45 W
- 25 - FEEDING CARD FUSE 1 A
- 26 - PRESS CONSENT SOCKET